






Quick Reference

These symbols are used in Controls & Features section:

| SYMBOL | COMPONENT | SEE PAGE |
|---|--|-----------------|
| q | ON — ignition switch | 34 |
| w | OFF — ignition switch | 34 |
|  | 4WD switch | 35 |
|  | differential lock switch | 36 |
|  | differential lock indicator — lights when the front differential lock mode engages | 36 |
|  | start/over ride button | 39 |
| e | RUN — engine stop switch | 40 |
| r | OFF — engine stop switch | 40 |
| y | ON — headlight switch | 41 |
| t | OFF — headlight switch | 41 |
| u | HI — headlight dimmer switch | 41 |
| i | LO — headlight dimmer switch | 41 |
|  | parking brake/reverse lever (P/R (lever): P — parking brake R — riding in reverse | 45 |