

Index

starting,	
engine	78
troubleshooting	206
stop switch, engine	40
stopping engine	83
storage,	
ATV	198
owner's manual	119
suspension,	
adjustment	163
spring pre-load	164
switch,	
4WD	35
differential lock	36
engine stop	40
headlight	41
headlight dimmer	41
ignition	34

T

tank cover assembly removal	122
throttle,	
cable	154, 155
lever	43, 154, 155
tires,	
air pressure	175
flat	209
repairing	179
replacing	180
thread conditions	177, 178
tool kit	118
trailer hitch	48