
## **Controls & Features**

## **Headlight Switch**



LEFT HANDLEBAR



The headlight switch (1) is used to turn the headlights and assist headlight ON ( $\stackrel{*}{\Rightarrow}$ ) or OFF ( $\bullet$ ). To operate, turn the switch to ON ( $\stackrel{*}{\Rightarrow}$ ) or OFF ( $\bullet$ ).

## **Headlight Dimmer Switch**



The headlight dimmer switch (2) is used to change between the high and low beams of the headlight. To operate, turn the switch to  $HI(\ \Box \ \Box)$  for high beam,  $LO(\ \Box \ \Box)$  for low beam.

The headlight dimmer switch will not change the assist headlight beam.