


Indicators & Displays

Tripmeter

The tripmeter has two sub modes, A (3) and B (4).

To change the display from tripmeter A or tripmeter B to odometer, press and release the odometer/tripmeter select button (2).



To reset the tripmeter to zero, press and hold the RESET button (5) for more than 2 seconds with the display in the tripmeter A or tripmeter B mode.

