

Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.
Check with your Honda dealer's parts department.

Importance of Maintenance	P. 60	Throttle	P. 96
Maintenance Schedule	P. 62	Other Adjustments	P. 98
Maintenance Fundamentals	P. 65	Adjusting the Headlight Aim	P. 98
Removing & Installing Body Components ..	P. 77	Adjusting the Clutch and Brake Levers	P. 99
Battery	P. 77	Adjusting the Front Suspension	P. 100
Clip	P. 78	Adjusting the Rear Suspension	P. 102
Right Engine Heat Guard & Right Under		Adjusting the Windscreen Height	P. 104
Cowl	P. 78		
Seat	P. 80		
Engine Oil	P. 81		
Coolant	P. 88		
Brakes	P. 90		
Side Stand	P. 94		
Clutch	P. 95		