

- Side Stand 77
Side Stand Ignition Cut-off System 77
Spark Plugs 61
Specifications 127
Speedometer 22
Start Button 26
Starting the Engine 28
Steering Lock 27
Stopping Engine 107
Storage
 Equipment 32
 Owner's Manual 33
 Tool Kit 34
Storing Your Motorcycle 110
Switches 26
- T**
Throttle 81
- Tires**
 Air Pressure 50
 Puncture 91
 Replacing 50, 91
Transporting Your Motorcycle 111
- Tripmeter 22, 107
Troubleshooting 86
Turn Signal Indicator 25
Turn Signal Switch 26
- V**
Vehicle Identification Number 113
- W**
Warning Indicators On or Flashing 89
Warranty Coverage and Service 123
Washing Your Motorcycle 108
Weight Limit 16, 127
- Wheels**
 Front Removal 92
 Rear Removal 95