Instruments (Continued) To set the clock:

io set the clock.

- !a Turn the ignition switch on.
- With odometer displayed, press and hold the mode switch until the clock digits start flashing.

- ! Press the mode switch until the desired time is displayed.
 - The time is advanced by one minute, each time the switch is pressed.
 - ► The time is advanced by ten minutes, when the switch is pressed and held.

- Id Wait for 5 seconds and press mode switch. The clock is set.
 - ► The time can also be set by turning the ignition switch off.