


## ■ Cancelling the Anti-theft Alarm System

To cancel the anti-theft alarm system, press the alarm button on the Honda SMART Key or unlock the ignition switch. ➡P.32

When the alarm button is pressed, the turn signal light and alarm indicator blink 2 times, and the buzzer rings 2 times.

When the ignition switch is unlocked, the turn signal light blinks, the buzzer rings 2 times and the alarm indicator goes off.

**Alarm button**



## ■ Stopping the Anti-theft Alarm Activation

To stop the anti-theft alarm activation, do one of the following:

- Press the alarm button on the Honda SMART Key.
- Press the answer back button on the Honda SMART Key.
- Unlock the ignition switch. ➡P.32

After stopping the anti-theft alarm activation, the anti-theft alarm system will be cancelled.

**Alarm button**

**Answer back button**

