

Refuelling

Fuel type: Unleaded petrol only

Fuel octane number: Your scooter is designed to use Research Octane Number (RON) 91 or higher.

Tank capacity: 8.0 L (2.11 US gal, 1.76 Imp gal)

Refuelling and Fuel Guidelines ➔ P.9

Opening the Fuel Fill Cap

- 1 Turn the ignition switch to the position of SEAT FUEL.
 - ▶ To unlock the ignition switch. ➔ P.32
- 2 Push the FUEL side of the fuel lid and seat opener switch.
 - ▶ The fuel lid opens.

