

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

Importance of Maintenance	P. 61	Crankcase Breather	P. 95
Maintenance Schedule	P. 62	Other Adjustments	P. 96
Maintenance Fundamentals	P. 65	Adjusting the Headlight Aim	P. 96
Tool	P. 75	Other Replacement	P. 97
Removing & Installing Body Components ..	P. 76	Replacing the Honda SMART Key Battery.....	P. 97
Battery	P. 76		
Battery Cover.....	P. 77		
Front Lid.....	P. 78		
Spark Plug	P. 79		
Engine Oil	P. 82		
Coolant	P. 86		
Brakes	P. 88		
Side Stand	P. 93		
Throttle	P. 94		