

## Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A pre-ride inspection is a must, not only for safety, but because having a breakdown, or even a flat tyre, can be a major inconvenience.

Check the following items before you get on your scooter:

- Fuel level - Fill fuel tank when necessary. ➤ P. 54
  - Throttle - Check for smooth opening and full closing in all steering positions. ➤ P. 94
  - Engine oil level - Add engine oil if necessary. Check for leaks. ➤ P. 82
  - Coolant level - Add coolant if required. Check for leaks. ➤ P. 86
- Brakes - Check operation; Front: check brake fluid level and pads wear. ➤ P. 88, ➤ P. 89  
Combi Brake: check brake fluid level. ➤ P. 88  
Rear: check shoes wear and freeplay, adjust if necessary. ➤ P. 89, ➤ P. 92
  - Lights and horn - Check that lights, indicators and horn function properly.
  - Side stand ignition cut-off system - Check for proper function. ➤ P. 93
  - Wheels and tyres - Check condition, air pressure and adjust if necessary. ➤ P. 71