

## Front Lid

### Removal

Pull out the front lid backward while pushing the side of the front lid.

### Installation

Install the part in the reverse order of removal.

Make sure that all tabs are installed securely in position.

