
Refuelling

Fuel fill cap



Do not fill with fuel above the lower edge of the filler neck.

Fuel type: Unleaded petrol only

Fuel octane number: Your motorcycle is designed to use Research Octane Number (RON) 91 or higher.

Tank capacity: 12.0 litres (3.17 US gal, 2.64 Imp gal)

Reserve capacity: 3.5 litres (0.92 US gal,

0.77 Imp gal)

Refuelling and Fuel Guidelines **R13** Opening the Fuel Fill Cap

Open the lock cover, insert the ignition key, and turn it clockwise to open the fuel fill cap.

Closing the Fuel Fill Cap

After refuelling, push the fuel fill cap closed until it locks.

2 Remove the key and close the lock cover.

The key cannot be removed if the fuel fill cap is not locked.

AWARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.