
## Checking the Drive Chain Slider/Slipper/Guide Slider

Check the condition of the drive chain slider. The drive chain slider need to be replaced if it is worn to the wear limit.

## **Chain slider thickness limit:** 0.16 in (4.0 mm)

If necessary have the drive chain slider replaced by your dealer.



Maintenance