


# Instruments

## Gear range indicator

Shows proper speed range for each gear.

## Speedometer

This shows your speed in miles (USA) or kilometers (Canada) per hour.



## Tripmeter reset knob

## Odometer

Total distance ridden.

- USA: Odometer & Tripmeter read in miles.
- Canada: Odometer & Tripmeter read in kilometers.

## Tripmeter

Distance ridden since you last reset the meter. (Turn the tripmeter reset knob as shown to reset to zero (0)).