

## Drive Chain ► Checking the Drive Chain Slider/Slipper/Guide Slider

Check the condition of the drive chain slipper and drive chain guide slider.

The drive chain slipper needs to be replaced if it is worn to the wear limit.

### **Chain slipper thickness limit:**

0.08 in (2.0 mm)

The drive chain guide slider needs to be replaced if the chain is visible through the wear inspection window.

If necessary have the drive chain slipper and drive chain guide slider replaced by your dealer.

