

# Troubleshooting

<b>Engine Will Not Start</b> .....	P. 84
<b>Tire Puncture</b> .....	P. 85
<b>Electrical Trouble</b> .....	P. 91
Battery Goes Dead.....	P. 91
Burned-out Light Bulb.....	P. 91
Blown Fuse.....	P. 94