
Switches (Continued) Steering Lock

Lock the steering when parking to help prevent theft.

A U-shaped wheel lock or similar device is also recommended.



Locking

1 Turn the handlebar all the way to the left.

2 Push the key down, and turn the ignition switch to the LOCK position.

► Jiggle the handlebar if the lock is difficult to engage.

3 Remove the key.

Unlocking

Insert the key, push it in, and turn the ignition switch to the OFF position.