


D 3

**F - 2
HANDLE LEVER -
SWITCH, CABLES**



F.R.T.	Ref. N°	Part N°	Description	DX 50								PA 50			
				VH-B	VK-B	MH-B	MK-B	VCH-B	VCK-B	MVCH-B	MVCK-B	MH-D	VH-DK	VH-F	VH-NL
0.2	1	14950-148-470	CABLE COMP. DECOMP.	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.3	2	17910-148-470	CABLE COMP. THROTTLE	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	3	32109-148-470	SUB CORD WINKER SWITCH					(1)	(1)	(1)	(1)				(1)
	3A	35303-GB7-640	CORD DIMMER HORN SWITCH												(1)
0.1	4	35200-148-000	SWITCH ASSY WINKER					(1)	(1)	(1)	(1)				(1)
		35300-143-603	SWITCH ASSY DIMMER												(1)
	5	38110-148-610	BELL	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
	6	38701-148-400	BAND STEERING					(2)	(2)	(2)	(2)				(2)
0.2	7	43450-GB7-970	CABLE COMP. RR. BRAKE	(1)		(1)		(1)		(1)		(1)	(1)	(1)	(1)
		43450-GB7-890	CABLE COMP. RR. BRAKE		(1)		(1)		(1)		(1)				(1)
0.1	8	45450-GB7-641	CABLE COMP. FR. BRAKE												(1)
		45450-GB7-970	CABLE COMP. FR. BRAKE	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	9	53002-GB7-610	HANDLE GRIP, THROTTLE ASSY	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
	9A	53010-148-370	HOLDER GRIP HANDLE R.	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
	10	55143-122-690	PIPE, THROTTLE GRIP	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	11	53165-093-003	RUBBER GRIP RIGHT	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	12	53166-093-003	RUBBER GRIP LEFT	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	13	53170-148-610	LEVER R. HANDLE PIPE	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	14	53172-GB7-710	HOLDER COMP. HANDLE GRIP L.	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	15	53180-148-610	LEVER L. HANDLE PIPE	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)
0.1	16	53182-122-690	LEVER, CHOKE	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)	(1)