


F-4 FRONT WHEEL-FRONT AXLE

F-4 FRONT WHEEL-FRONT AXLE

Ref. No.	Part No.	Description	Reord. No. ATC 90	No. Used on	
				From	To
1	44301-918-020	AXLE, front wheel	1		
2	44302-918-000	COLLAR, front axle	2		
3	44311-918-000	COLLAR, front wheel side	1		
4	44601-918-030	HUB, front wheel	1		
5	44620-918-010	COLLAR, front axle distance	1		
6	44710-918-007	TIRE, front wheel (OHTSU)	1		
7	91201-918-025	DUST-SEAL, 20x35x8 (NIPPON OIL SEAL)	2		
8	92009-08025-01A	BOLT, hex, 8x25	3		
9	94011-12000-0S	NUT, castle, 12mm	2		
10	94111-08000	WASHER, spring, 8mm	3		
11	94111-12000	WASHER, spring, 12mm	2		
12	94201-30300	PIN, split, 3mm	2		
13	96100-60030	BEARING, ball, 6003	2		



I.A.