



DRIVE FACE



GZ44-E0600

DRIVEN FACE



GZ44-E0700A

EZ90 '91			QTY REQ	ENGINE SERIAL NUMBER		PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-6					
				FROM	TO		
21	WASHER, THRUST, 14MM.....		1			90451-001-000	0004671
22	WASHER, THRUST, 20X1.00.....		1			90454-428-000	0684902
23	NUT, FLANGE, 10MM.....		1			94050-10000	0483867
24	CIRCLIP, EXTERNAL, 14MM.....		1			94511-14000	0417295

EZ90 '91			QTY REQ	ENGINE SERIAL NUMBER		PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-7					
				FROM	TO		
1	OUTER COMP., CLUTCH.....		1			22101-GZ4-670	3446820
2	PLATE COMP., DRIVE.....		1			22350-GZ4-670	3446945
3	SPRING, CLUTCH.....		3			22401-GZ4-670	3446986
4	SPRING, CLUTCH.....		2			22402-GZ4-670	3446994
5	WEIGHT SET, ENGINE BRAKE.....						
	CLUTCH.....		1			22525-GZ4-305	3460615
6	WEIGHT SET, CLUTCH.....		1			22535-GZ4-305	3460623
7	RUBBER, CLUTCH DAMPER.....		2			22804-GM8-670	2062891
8	RUBBER, CLUTCH DAMPER.....		3			22804-148-000	1030212
9	BELT, DRIVE.....		1			23100-GZ4-671	3447109
10	FACE ASSY., DRIVEN.....		1			23200-GZ4-670	3447125
11	FACE COMP., MOVABLE DRIVEN.....		1			23220-GZ4-670	3447141
12	PIN, ROLLER GUIDE.....		3			23225-GW3-000	3447166
13	ROLLER, GUIDE.....		3			23226-GW3-000	3447174
14	SPRING, DRIVEN FACE.....		1			23233-GZ4-670	3447182
15	COLLAR, SEAL.....		1			23237-GW3-000	3447190
16	COLLAR, SPRING.....		1			23238-GZ4-670	3447208
17	NUT, SPECIAL, 28MM.....		1			90202-GZ4-670	3453313
18	WASHER, 10MM.....		1			90410-KR0-000	2306306
19	WASHER, THRUST, 6MM.....		2			90442-G82-000	1706076
20	WASHER, THRUST.....		3			90442-GK1-003	1915024

CONTENTS

TITLE	GRID	PAGE
AIR CLEANER	C10	39
BATTERY	C10	38
BODY COVER	C3	25
CARBURETOR	B8	17
CAUTION LABEL	D4	51
CENTER COVER	C3	24
CRANKCASE	B6	13
CRANKSHAFT	B7	15
CYLINDER	B1	3
DRIVE FACE	B3	7
DRIVEN FACE	B4	9
EXHAUST MUFFLER	C11	41
FAN COVER	B1	2
FRAME BODY	D3	49
FRONT BRAKE PANEL	C6	30
FRONT COVER	C2	23
FRONT FORK	C4	27
FRONT WHEEL	C6	31
FUEL TANK	C8	35
GASKET KIT	B9	19
GENERATOR	B2	4
HANDLE COVER	C2	22
LEFT CRANKCASE COVER	B3	6
MARK	D5	52
OIL TANK	C9	37
PEDAL	C12	42
REAR BRAKE PANEL	C7	32
REAR CUSHION	D2	46
REAR FENDER	D2	47
REAR WHEEL	C7	33
SEAT	C8	34
STARTING MOTOR	B2	5
STEP	C12	43
SWING ARM	D1	45
SWITCH	C1	20
TOOLS	D4	50
TRANSMISSION	B5	11
WIRE HARNESS	D3	48