


# SWITCH



EZ90 '91		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. F-1 DESCRIPTION			
1	CABLE SET, THROTTLE.....	1	17920-G24-305	3460607
2	BULB WEDGE BASE (12V 3.4W).....	2	34908-GA7-701	1084672
3	SWITCH ASSY., KILL.....	1	35130-G24-671	3448420
4	SWITCH ASSY., STARTER.....	1	35160-G24-671	3448446
5	SWITCH ASSY., FR STOP..... (TATEISHI)	1	35340-ML4-005	3468683
6	SOCKET COMP., PILOT.....	1	37560-G24-671	3448669
7	LENS COMP., WINKER PILOT.....	1	37561-G87-641	3084589
8	LENS COMP., SPEED WARNING.....	1	37561-MR7-000	3448677
9	SENSOR COMP., LOAD.....	1	43440-G24-670	3449204
10	NUT, BRAKE ADJUSTING.....	1	43464-958-000	0842633
11	CABLE COMP., FR. BRAKE.....	1	45450-G24-670	3449600
12	PIPE, THROTTLE GRIP.....	1	53141-GV9-741	3450707
13	GRIP, L. HANDLE.....	1	53166-GM9-740	3450749
14	HOUSING, UNDER THROTTLE.....	1	53167-GM2-020	3450756
15	GRIP SET, R. HANDLE.....	1	53168-GM9-315	3450772
16	HOUSING, UPPER THROTTLE.....	1	53168-GM2-020	3450780
17	LEVER, R. STEERING HANDLE.....	1	53175-GR2-000	2452423
18	LEVER, L. STEERING HANDLE.....	1	53178-G24-671	3450798
19	SCREW, SPECIAL, 4X12.....	1	90004-G24-670	3500154

EZ90 '91		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. F-1 DESCRIPTION			
20	SCREW, R. STEERING HANDLE..... LEVER PIVOT	2	90115-GF8-000	3460813
21	SCREW, PAN, 5X25.....	1	93500-05025-0A	0145565
22	NUT, HEX., 5MM.....	2	94001-05070-0S	1083278
23	SPRING B. BRAKE ROD.....	1	95014-73200	1798537
24	JOINT B. BRAKE ARM.....	1	95015-32001	0400945
25	BOLT, FLANGE, 6X16.....	1	95701-06016-00	2410892

CONTENTS		
TITLE	GRID	PAGE
AIR CLEANER.....	C10	39
BATTERY.....	C10	38
BODY COVER.....	C3	25
CARBURETOR.....	B8	17
CAUTION LABEL.....	D4	51
CENTER COVER.....	C3	24
CRANKCASE.....	B6	13
CRANKSHAFT.....	B7	15
CYLINDER.....	B1	3
DRIVE FACE.....	B3	7
DRIVEN FACE.....	B4	9
EXHAUST MUFFLER.....	C11	41
FAN COVER.....	B1	2
FRAME BODY.....	D3	49
FRONT BRAKE PANEL.....	C6	30
FRONT COVER.....	C2	23
FRONT FORK.....	L1	27
FRONT WHEEL.....	C6	31
FUEL TANK.....	C8	35
GASKET KIT.....	B9	19
GENERATOR.....	B2	4
HANDLE COVER.....	C2	22
LEFT CRANKCASE COVER.....	B3	6
MARK.....	D5	52
OIL TANK.....	C9	37
PEDAL.....	C12	42
REAR BRAKE PANEL.....	C7	32
REAR CUSHION.....	D2	46
REAR FENDER.....	D2	47
REAR WHEEL.....	C7	33
SEAT.....	C8	34
STARTING MOTOR.....	B2	5
STEP.....	C12	43
SWING ARM.....	D1	45
SWITCH.....	C1	20
TOOLS.....	D4	50
TRANSMISSION.....	B5	11
WIRE HARNESS.....	D3	48