



REAR CUSHION



GZ44-F2000

REAR FENDER



GZ44-F2100

"CAUTION OR WARNING LABELS MUST BE ORDERED SEPARATELY WHEN APPLICABLE"

EZ90 '91		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. F-20 DESCRIPTION			
	FRAME SERIAL NUMBER			
	FROM TO			
1	CUSHION ASSY., RR.....	1	52400-GZ4-671	3460714
2	BOLT, BALL JOINT (10X50).....	1	90120-SA7-010	1868900
3	BOLT, FLANGE, 10X56.....	1	90152-GC5-000	2544708
4	NUT, U, 10MM.....	2	90304-GE8-003	1439249

EZ90 '91		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. F-21 DESCRIPTION			
	FRAME SERIAL NUMBER			
	FROM TO			
1	FENDER, RR. *NH138*..... (SHASTA WHITE).....	1	80100-GZ4-670ZA	3452117
2	BOLT, FLANGE, 6MM.....	1	90111-162-000	0911141
3	SCREW, SPECIAL, 6X11.....	2	90381-GZ4-670	3453396

CONTENTS

TITLE	GRID	PAGE
AIR CLEANER.....	C10	39
BATTERY.....	C10	39
BODY COVER.....	C3	25
CARBURETOR.....	B8	17
CAUTION LABEL.....	D4	51
CENTER COVER.....	C3	24
CRANKCASE.....	B6	13
CRANKSHAFT.....	B7	15
CYLINDER.....	B1	3
DRIVE FACE.....	B3	7
DRIVEN FACE.....	B4	9
EXHAUST MUFFLER.....	C11	41
FAN COVER.....	B1	2
FRAME BODY.....	D3	49
FRONT BRAKE PANEL.....	C6	30
FRONT COVER.....	C2	23
FRONT FORK.....	C4	27
FRONT WHEEL.....	C6	31
FUEL TANK.....	C8	35
GASKET KIT.....	B9	19
GENERATOR.....	B2	4
HANDLE COVER.....	C2	22
LEFT CRANKCASE COVER.....	B3	6
MARK.....	D5	52
OIL TANK.....	C9	37
PEDAL.....	C12	42
REAR BRAKE PANEL.....	C7	32
REAR CUSHION.....	D2	46
REAR FENDER.....	D2	47
REAR WHEEL.....	C7	33
SEAT.....	C8	34
STARTING MOTOR.....	B2	5
STEP.....	C12	43
SWING ARM.....	D1	45
SWITCH.....	C1	20
TOOLS.....	D4	50
TRANSMISSION.....	B5	11
WIRE HARNESS.....	D3	48