


E-11 Dynamo · Starting Motor

E-11 Dynamo · Starting Motor



Ref. No.	Part No.	Description	No. Reqd.		Remarks
			CD 125	CD 125A	
21	32971-200-000	GROMMET, dynamo cord	1	1	
22	32971-205-000	GROMMET, cord	1		
23	35752-200-000	STATOR, neutral switch	1	1	
24	90701-250-000	PIN, knock 6x13.5	1		
25	91101-253-030	ROLLER, 10.2x9.5	3		
26	91201-201-010	OIL-SEAL, SC type, 18x27x5...	1		
27	91207-201-000	OIL-SEAL, SC type, 28x38x5.5	1		
	91207-240-000	OIL-SEAL, SC type 17.9x38x7.5	1		CD125E-1063468
28	92000-06030	BOLT, her., 6x30	2	2	
29	92000-06035	BOLT, hex., 6x35	2		
30	92000-06050	BOLT, hex., 6x50	2		
31	93500-06012	SCREW, cross, 6x12	2	2	
32	93500-06020	SCREW, cross, 6x20	1	1	
33	93500-06050	SCREW, cross, 6x50	6	6	
34	93600-06020	SCREW, cross, 6x20	3		
35	94111-06000	WASHER, spring, 6 mm	7	3	
36	94001-06000	NUT, hex., 6 mm	1	1	
37	31104-242-004	BOLT, dynamo rotor setting	1	1	
38	31105-242-004	WASHER, dynamo rotor setting	1	1	