



Rel. No.	Part No.	Description	No. Reqd.		Remarks
			CD 125	CD 125A	
1	32984-001-620	GROMET, horn (Used in France)	1	1	CD125-1029146~1123847
2	38100-230-000	(Superseded by 38100-230-010)	1	1	CD125-1012528~1123847
	38100-230-010	HORN ASSY.....	1	1	CD125-1123848
3	38101-230-620	CORD, horn (Used in France)...	1	1	CD125-1029146~1123847
4	38106-011-621	SCREW, horn setting ... (Used in France)	1	1	CD125-1029146~1123847
5	38111-230-620	STAY, horn (Used in France)...	1	1	CD125-1029146~1123847
6	50100-230-040B	BODY, frame (Black)	1	1	
	50100-230-040C	BODY, frame (Scarlet)	1	1	
	50100-230-040XJ	BODY, frame (Candy red).....		1	CD125-1089493
	50100-230-040XK	BODY, frame (Candy blue)	1		
	50100-230-040Z	BODY, frame (Non sanding).....	1	1	
	50100-230-620B	BODY, frame (Black)	1	1	CD125-1029146 (Used in France)
	50100-230-620C	BODY, frame (Scarlet).....	1	1	CD125-1029146 (Used in France)
	50100-230-620Z	BODY, frame (Non sanding).....	1	1	CD125-1029146 (Used in France)
7	50301-200-31E	RACE, top, steering ball.....	1	1	
8	50302-200-305	RACE, bottom, steering ball.....	1	1	
9	83500-230-030B	COVER, tool box (Black)	1	1	
	83500-230-030C	COVER, tool box (Scarlet).....	1	1	
	83500-230-030XJ	COVER, tool box (Candy red)...		1	CD125-1089493
	83500-230-030XK	COVER, tool box (Candy blue)...	1		
10	83600-230-030B	COVER, battery box (Black).....	1	1	
	83600-230-030C	COVER, battery box (Scarlet) ...	1	1	
	83600-237-680B	COVER, battery box (Black).....	1	1	CD125-1086253
	83600-237-680C	COVER, battery (Scarlet)	1	1	CD125-1086253
	83600-237-680XJ	COVER, battery box (Candy red)	1		CD125-1089493
	83600-237-680XK	COVER, battery box (Candy blue)	1		
11	83660-230-010	LATCH, battery cover	1	1	
	92300-06010	BOLT, castle, 6x10.....	1	1	CD125-1086253
12	87125-041-580	PLATE, name	1	1	
13	87501-230-630	PLATE, register number	1	1	CD125-1029146 (Used in France)
14	90841-001-000	SCREW, rever, 1.5x5.....	2	2	CD125-1029146
15	92000-06020	BOLT, hex., 6x20	2	2	