



Ref. No.	Part No.	Description	No. Reqd.		Remarks
			CD 125	CD 125A	
1	50600-230-000	COIL, ignition	1	1	
2	31500-230-020	BATTERY (6V-10.5AH)	1		CD125-1012628-1086252
	31500-237-570	BATTERY (6V-12Ah)	1		CD125-1086253
	31500-242-000	BATTERY (6V-6Ah)	1		CD125-1063196
3	31700-230-000	RECTIFIER, selenium	1		
	31700-242-000	RECTIFIER, selenium	1		CD125-1063196
4	32100-230-010	HARNESS, wire	1		CD125-1012628-1089544
	32100-330-020	HARNESS, wire	1		CD125-1089545
	32100-230-621	HARNESS, wire (Used in France)	1	1	CD125-1029146
	32100-242-000	HARNESS, wire	1		CD125-1063196-1089544
	32100-242-010	HARNESS, wire	1		CD125-1089545
	32101-242-810	HARNESS, sub, wire	1		CD125-1063196
5	32106-253-010	CONNECTOR B, fuse	1	1	CD125-1012628-1102990
	32111-230-000	CASE, fuse connector	1		CD125-1102991
	32106-046-000	CONNECTOR B, fuse	1		CD125-1090101
6	32112-253-010	CONNECTOR A, fuse	1	1	CD125-1012628-1102990
	32112-230-000	CONNECTOR, fuse	1		CD125-1102991
	32112-041-000	CONNECTOR A, fuse	1		CD125-1090101
7	32601-237-630	CABLE, battery earth	1	1	
8	32984-071-620	GROMMET, horn	1	1	CD125-1020146
		(Used in France)			
9	35010-230-010	SWITCH KEY, combination	1	1	
10	35860-230-000	SWITCH, starter magnetic	1	1	
11	39101-230-620	CORD, horn (Used in France) ...	1	1	CD125-1029146
12	39108-011-620	SCREW, horn setting	1	1	CD125-1029146
		(Used in France)			
13	39111-030-620	STAY, horn (Used in France) ...	1	1	CD125-1029146
14	39300-230-000	FUSE	4	4	
15	39300-230-040	RELAY, winker	1	1	CD125-1012628-1089544
	39300-230-044	RELAY, winker	1	1	CD125-1089545
	39300-237-600	RELAY, winker	1		CD125-1089501
		(Used in France)			
16	52000-08008	BOLT, hex, 6x8	2	2	
17	94001-08000	NUT, hex, 6mm	6	6	
18	94101-08000	WASHER, flat, 6mm	6	6	