


F-4 Fuel Tank • Air Cleaner • Seat • Side Cover

F-4 Fuel Tank • Air Cleaner • Seat • Side Cover



Ref. No.	Part No.	Description	Reqd. No. CR125M	Serial No.	Area Code
1	16950-360-000	COCK ASSY., FUEL	1		
2	16997-357-003	O-RING, 11.8X2.4	1		
3	17211-360-000	BASE, AIR CLEANER	1		
4	17212-360-000	ELEMENT, AIR CLEANER	1		
5	17213-360-000	HOLDER, AIR CLEANER ELEMENT	1		
6	17253-360-000	TUBE, AIR CLEANER CONNECTING	2		
7	17256-360-000	BAND A, CLEANER CONNECTING TUBE	1		
8	17257-360-000	BAND B, CLEANER CONNECTING TUBE	1		
9	17500-360-306SS	TANK COMP., FUEL	1		
10	17507-357-000	RUBBER, FUEL TANK MOUNT	2		
11	17507-360-000	RUBBER, FUEL TANK MOUNT	1		
12	17508-357-000	COLLAR, FUEL TANK SETTING	3		
13	17510-357-000	CAP ASSY., FUEL TANK	1		
14	17520-357-000	TUBE, FUEL CAP BREATHFR	1		
15	17624-098-010	GASKET, FUEL FILLER CAP	1		
16	61104-357-000	COLLAR, FR. FENDER	1		
17	77100-360-000	SEAT ASSY.	1		
18	83500-360-000SS	COVER, R. SIDE	1		
19	83503-360-000	BAND, SIDE COVER	2		
20	83504-350-000	RUBBER, SIDE COVER SETTING	1		
21	83600-360-000SS	COVER, L. SIDE	1		
22	87203-360-670	EMBLEM, SIDE COVER	2		
23	92501-040-000	WASHER, SEAT SETTING	3		
24	92000-06016	BOLT, HEX., 6X16	2		
25	92000-06022	BOLT, HEX., 6X22	4		
26	92000-08016-0A	BOLT, HEX., 8X16	1		
27	92000-08020-0A	BOLT, HEX., 8X20	1		
28	93520-04025-0A	SCREW, PAN, 4X25	2		
29	94001-06000	NUT, HEX., 6MM	1		
30	94101-06000	WASHER, PLAIN, 6MM	1		
31	94101-08000	WASHER, PLAIN, 8MM	2		
32	94101-06030	WASHER, SPRING, 6MM	1		
33	94111-08000	WASHER, SPRING, 8MM	2		
34	94251-06000	PIN, LOCK, 6MM	1		
35	95001-55180-40	TUBE, FUEL, 5.5X180	1		
36	95002-02100	CLIP B10, TUBE	2		
37	95002-50000	CLIP C9, TUBE	1		