

INSTRUCTION FOR USE OF PARTS LIST

Ordering Replacement Parts

- Replacement Parts orders are accepted at HONDA Overseas Subsidiary or HONDA Authorized Dealer at your locality.
- Order each replacement part by the part number and its model serial number. Whenever any modification or addition to the replacement parts are made, a revised edition which has a progressively advanced edition number at left bottom of the front cover page will be issued. It is recommended that you purchase the newest edition to always receive correct parts.

Make-up and Use of Parts List

- This Parts List contains all the replacement parts for Model CR125M1.
- In order to simplify location of a desired part, all component parts are divided into two groups; engine parts and frame parts and illustrate in two whole illustrations respectively.
- All part numbers, engine part or frame part numbers, are listed up in numerical order.
- When it is desired to check the appearance of a given part from its part number, the group number of the part in the text page may be cross-referred to the corresponding group number in the illustration chart.
- The part number described under the part description supersedes the part number ahead.
- Reqd. No. (Abbrev. of Required Number) indicates the quantity of the part which can be used within the corresponding group.
- All dimensions are shown in millimeters except steel balls and wheel related parts.

Color Code and Color Description

Color code	Color description	Remarks
B	Black	Frame body, Rear fork
NH	Tahitian red & black	Fuel tank
NQ	Custom silver metallic	Front fender Rear fender
SG	Semi glazed black	Steering stem Fork top bridge
SH	Mat black	Expansion chamber
UQ	Tahitian red & phantomblack	Side cover

Abbreviations

The following abbreviations are used in this Parts List.

ASSY. Assembly	W Watt
COMP. Complete	KPH Kilometers per hour
R. Right	MPH Miles per hour
L. Left	L (100L) Link (100 Links)
STD. Standard	A.C. Alternating current
MM Millimeter	D.C. Direct current
G Gram	IN. Inlet
T (22T) Tooth (22 Teeth)	EX. Exhaust
A Ampere	FR. Front
V Volt	RR. Rear
	HEX. Hexagonal


Applicable Serial Number and Stamped Location

All engine component parts are controlled by the engine serial number and all frame component parts by the frame serial number.

The initial engine and frame serial numbers are as follows.

Model Area code	Type Description	Initial Engine serial No.	Initial Frame serial No.
CR125M1	A	CR125ME-2000001~*	CR125M-2000006~2018555
	CM	CR125ME-2000001~*	CF.125M-2002396~2018817

The serial numbers are stamped on the following locations.



Applicable Carburetor Identification Number

Component parts of the carburetor are controlled by the carburetor identification number.

Make-up of the identification number is as follows.

(Example)

056 A A KC 7

Only this portion of the identification number is used for control purpose.

- The part number described under the part description supersedes the part number ahead.
- This parts list is compiled as of April 20, 1977.