


E - 19 - 20

Left Crankcase



KWNVE1920

Ref No.	(Relative ref. Number) Description	F.R.T.	Ref No.	Part No.	Description	QTY	Notes
1	CRANKCASE :LEFT	6,5	1	11200-KWN-900	CRANKCASE COMP., L.....	1	
	.TERMASUK: Pelepasan dan pemasangan mesin		2	12361-035-000	CAP, TAPPET ADJUSTING HOLE.....	1	
	CRANKCASE :BOTH	6,7	3	15421-KPL-900	SCREEN, OIL FILTER.....	1	
	.TERMASUK: Pelepasan dan pemasangan mesin		4	15426-KVB-900	SPRING, OIL FILTER SCREEN.....	1	
3	SCREEN, OIL FILTER	0,2	5	32105-KWN-900	SUB CORD, SPEED SENSOR.....	1	
5	(6) SUB CORD, SPEED SENSOR.....	1,1	6	32112-KWN-900	PROTECTOR, SPEED SENSOR.....	1	
8	SENSOR, WHEEL SPEED :REAR.....	1,2	7	32113-KWN-900	GROMMET, SPEED SENSOR.....	1	
12	BEARING, CRANKSHAFT :LEFT	5,8	8	37700-HP5-601	SENSOR ASSY., SPEED.....	1	
	.TERMASUK: Pelepasan dan pemasangan mesin		9	90001-KWR-000	BOLT, SOCKET, 6X18.....	2	
13	BEARING, COUNTERSHAFT :LEFT.....	1,1	10	90032-KWN-900	BOLT B, STUD, 8X206.....	2	
	BEARING, COUNTERSHAFT :BOTH ..	1,2	11	90495-MN5-000	WASHER, SEALING, 8MM.....	1	
14	BEARING, FINAL GEAR SHAFT :LEFT	1,1	12	91002-KWN-901	BEARING, RADIAL BALL, 6207.....	1	
	BEARING, FINAL GEAR SHAFT :BOTH.....	1,2	13	91005-KWN-901	BEARING, RADIAL BALL, 6301.....	1	
15	BEARING, DRIVESHAFT :LEFT.....	1,2	14	91008-KWN-901	BEARING, RADIAL BALL, 6302.....	1	
	BEARING, DRIVESHAFT :BOTH	1,3	15	91104-KN7-670	BEARING, RADIAL BALL, 6204.....	1	
16	OIL SEAL, CRANKSHAFT :LEFT	5,8	16	91202-KWN-901	OIL SEAL, 26X45X6.....	1	
	.TERMASUK: Pelepasan dan pemasangan mesin		17	91203-KWN-901	OIL SEAL, 20X32X6.....	1	
	OIL SEAL, CRANKSHAFT :BOTH	5,9	18	91302-001-020	O-RING, 30.8MM.....	1	
	.TERMASUK: Pelepasan dan pemasangan mesin		19	91303-KF0-003	O-RING, 14.8X2.4.....	1	
17	OIL SEAL, DRIVESHAFT.....	1,2	20	95701-0601600	BOLT, FLANGE, 6X16.....	1	
			21	95701-0801600	BOLT, FLANGE, 8X16.....	1	
			22	11103-KVB-901	BUSH, ENGINE HANGER RUBBER.....	1	
			23	11203-KVB-901	BUSH, RR. CUSHION UNDER RUBBER.....	1	
			24	11205-GBC-300	BUSH, MAINSTAND.....	1	