

PART NAME INDEX

Part name	Page	Ref.	Part name	Page	Ref.	Part name	Page	Ref.
CIRCLIP, INTERNAL, 40MM	68	5	COVER, CENTER	62	3	[F]		
CLAMPER A, BRAKE HOSE	53	3	COVER, ENGINE CONTROL UNIT	80	2	FACE COMP., MOVABLE DRIVE	38	4
CLAMPER B, BRAKE HOSE	53	4	COVER, FR.	57	2	FACE SET, DRIVEN	39	8
CLAMPER B, RR. BRAKE CABLE	51	9	COVER, FR. LOWER	60	1	FACE SET, MOVABLE DRIVEN	39	9
CLAMPER, A.C. GENERATOR CORD	43	10	COVER, FUEL TANK	70	12	FACE, DRIVE	38	2
CLAMPER, THROTTLE CABLE	51	2	COVER, HANDLE FR. TOP	54	3	FAN COMP., COOLING	36	16
CLAMP, HOSE	36	20	COVER, INNER LOWER	58	10	FENDER ASSY., RR. INNER	77	10
CLAMP, TUBE	37	21	COVER, L. BODY SIDE	63	7	FENDER B, RR.	77	5
CLAMP, WATER HOSE, 21MM	71	15	COVER, L. BRAKE LEVER BRACKET	51	14	FENDER SET A, RR.	77	4
CLAMP, WATER HOSE, 24MM	36	21	COVER, L. SIDE	35	1	FENDER SET, FR.	56	1
CLIP, BUMPER SEAL	32	7	COVER, L. UNDER SIDE	62	2	FILTER SET	70	3
CLIP, HOSE	60	8	COVER, RACK	58	8	FLYWHEEL COMP.	33	1
CLIP, PISTON PIN, 14MM	46	5	COVER, RESERVE TANK	77	6	FOB ASSY.	80	10
CLIP, SNAP FITTING	54	13	COVER, RR. CENTER	63	8	FORK ASSY., L. FR.	64	14
CLIP, TRIM	77	18	COVER, RR. FENDER LOWER	77	9	FORK ASSY., R. FR.	64	1
CLIP, TUBE	41	16	COVER, RR. FENDER UPPER	77	7	FUEL UNIT	70	15
COIL COMP., IGNITION	83	6	COVER, R. BODY SIDE	62	5	FUSE, MINI	79	7
COLLAR	80	3	COVER, R. UNDER SIDE	62	1			8
COLLAR A, HANDLE SETTING	36	12	COVER, SEAT CATCH	69	7	[G]		
COLLAR B, HANDLE SETTING	54	11	COVER, UNDER	60	4	GARNISH, FR.	57	3
COLLAR B, RR. WHEEL SIDE	68	2	COVER, UNDER	60	4	GARNISH, L. FR.	60	5
COLLAR, AIR CLEANER SETTING	71	1	CRANKCASE COMP., L.	44	2	GARNISH, L. INNER	57	5
COLLAR, FR. DISTANCE	66	5	CRANKCASE COMP., R.	43	1	GARNISH, R. FR.	60	3
COLLAR, FR. WHEEL SIDE	66	3	CRANKSHAFT COMP.	46	1	GARNISH, R. INNER	57	4
COLLAR, HORN SETTING	80	17	CUSHION ASSY., RR.	74	1	GASKET, CYLINDER	31	2
COLLAR, MUFFLER PROTECTOR	72	5	CYLINDER ASSY., FR. MASTER	53	5	GASKET, CYLINDER HEAD	26	3
COLLAR, RR. WHEEL SIDE	68	1	CYLINDER COMP.	31	1	GASKET, CYLINDER HEAD COVER	25	2
COLLAR, SEAL	39	13	CYLINDER SET, MASTER	53	12	GASKET, EX. PIPE	72	2
COLLAR, SPRING	39	14	DIAPHRAGM	53	11	GASKET, L. COVER	35	2
COLLAR, WINKER	75	2	DISK, FR. BRAKE	66	8	GASKET, STATOR BASE	43	8
CONTROL UNIT SET, SMART	80	11	DOWEL PIN, 10X12	41	15	GASKET, TENSIONER LIFTER	30	5
CONTROL UNIT, ENGINE	80	1	DOWEL PIN, 10X16	26	5	GASKET, TRANSMISSION CASE	41	4
COTTER, VALVE	28	12	DOWEL PIN, 3X5	26	16	GASKET, WATER PUMP COVER	32	3
COVER COMP., CYLINDER HEAD	25	1	DOWEL PIN, 8X10	32	9	GAUGE, OIL LEVEL	43	9
COVER COMP., HANDLE RR.	54	4	DOWEL PIN, SPECIAL, 6-3X10X30-DRIVER, SCREW	34	4	GEAR COMP., FINAL	41	8
COVER COMP., RADIATOR	36	10	DOWEL PIN, 8X14	43	18	GEAR, COUNTER	41	7
COVER COMP., WATER PUMP	32	2	DOWEL PIN, 8X14	35	11	GEAR, OIL PUMP DRIVEN	34	2
COVER SET, FR. TOP	57	1	DOWEL PIN, SPECIAL, 6-3X10X30-DRIVER, SCREW	43	14	GRIP	84	2
COVER SET, HANDLE FR.	54	5	DUCT, AIR CLEANER	84	1	GRIP COMP., THROTTLE	51	11
COVER SET, L. BODY	62	6	DUCT, AIR CLEANER	71	4	GRIP, L. HANDLE	51	12
COVER SET, L. FR.	63	6	DUCT, L. COVER	35	3	GROMMET, SPEED SENSOR	44	10
COVER SET, R. BODY	58	7	DUST SEAL, 21X32X5	66	12	GUARD, DUCT	82	10
COVER SET, R. FR.	62	4	DUST SEAL, 25X35X6	68	8	GUARD, ENGINE CONTROL UNIT	82	7
COVER SUB ASSY., AIR CLEANER	71	8	DUST SEAL, 25X40X5	68	7	GUARD, SPLASH	77	8
COVER, BATTERY	79	6	DUST SEAL, STEERING HEAD	55	8	GUIDE, CAM CHAIN	30	6
COVER, CABLE	80	12	ELEMENT COMP., AIR CLEANER	71	2	GUIDE, VALVE	26	2
			EMBLEM,	86	5	[H]		
			EMBLEM, BODY COVER	86	7	HARNISS, WIRE	80	6
			EMBLEM, PRODUCT	54	6	HEAD ASSY., CYLINDER	26	1
			EQUALIZER COMP.	51	16	HOLDER, MIRROR	51	10
			E-RING, 3MM	52	25	HOOK, LUGGAGE	53	9
						HORN COMP.	58	9
							80	15