

| | | |
|----|----------------------|----------------|
| 1 | SWITCH, STOP LAMP | 35351-259-000 |
| 2 | ROD, RR. BRAKE | 43450-200-000 |
| 2 | ROD, RR. BRAKE | 43451-230-000 |
| 2 | ROD, RR. BRAKE | 43451-235-000 |
| 3 | JOINT, BRAKE ARM | 43453-250-000 |
| 3 | JOINT, BRAKE ARM | 95015-32000 |
| 3 | JOINT, BRAKE ARM | 95015-32001 |
| 4 | SPRING, RR. | 43472-212-000 |
| 4 | SPRING A, BRAKE ROD | 95014-73100 |
| 4 | SPRING A, BRAKE ROD | 95014-73300 |
| 5 | PIN, BRAKE ROD JOINT | 43472-250-000 |
| 5 | PIN A | 95015-51000 |
| 6 | NUT B | 43486-250-000 |
| 6 | NUT B | 95015-42000 |
| 7 | ARM ASSY. | 43510-200-000 |
| 8 | PEDAL, BRAKE | 46500-200-000 |
| 9 | SPRING, BRAKE PEDAL | 46514-200-000 |
| 10 | STAND, MAIN *NH1* | 50500-201-010B |
| 11 | SPRING, MAIN STAND | 50522-200-000 |
| 12 | HOOK | 50523-200-000 |
| 13 | RUBBER | 50524-200-010 |
| 13 | RUBBER | 50524-212-000 |
| 14 | COLLAR | 50525-200-000 |
| 15 | BAR, SIDE STAND | 50530-200-010 |
| 16 | SPRING, SIDE STAND | 50542-200-000 |
| 16 | SPRING, SIDE STAND | 95014-72200 |
| 16 | SPRING B, SIDE STAND | 95014-72201 |
| 16 | SPRING B, SIDE STAND | 95014-72203 |
| 16 | SPRING, SIDE STAND | 95014-72204 |
| 17 | BAR, STEP *NH1* | 50610-201-010B |
| 18 | RUBBER, STEP | 50661-200-000 |
| 18 | RUBBER, STEP | 50661-204-000 |
| 19 | BOLT | 90108-200-000 |
| 20 | SCREW | 90128-200-000 |
| 21 | BOLT | 90151-201-000 |
| 22 | WASHER (21.5MM) | 90522-200-000 |
| 23 | NUT, HEX. (8MM) | 94001-08000 |
| 23 | NUT, HEX. (8MM) | 94030-08000 |
| 23 | NUT, HEX. (8MM) | 94030-08200 |
| 24 | NUT, HEX. (10MM) | 94002-10000 |
| 24 | NUT, HEX. (10MM) | 94002-10000-0S |
| 24 | NUT, HEX. (10MM) | 94002-10000-08 |
| 25 | WASHER, SPRING (8MM) | 94111-08000 |
| 26 | PIN, COTTER (2.0X15) | 94201-20150 |
| 27 | PIN, COTTER (3X30) | 94201-30300 |
| 27 | PIN, COTTER (3.0X40) | 94201-30400 |
| 27 | PIN, COTTER (3.0X45) | 94201-30450 |

