


# F-37

# BATTERY



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	610100	BATTERY .....	0.2
2	6111F8	SUB HARNESS, BATTERY .....	1.0
3	615113	SWITCH, STARTER MAGNETIC .....	1.0
5	410185	BOX, BATTERY .....	1.0

3

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			FS 150F H		
1	31500-KWN-901	BATTERY (YTZ6V) (YUASA) .....	1		
2	32103-K56-N10	SUB HARNESS, BATTERY .....	1		
3	35850-K56-N01	SWITCH ASSY., STARTER MAGNETIC .....	1		
4	35856-K56-N00	RUBBER, SHOCK (MAGNETIC) .....	1		
5	50320-K56-N00	BOX COMP., BATTERY .....	1		
6	50330-K56-N10	COVER ASSY., BATTERY .....	1		
7	90116-KVB-900	BOLT, FLANGE, 6MM .....	1		
8	90132-K45-N00	SCREW, PAN, 6X18.5 .....	1		
9	90305-GK8-000	NUT, CLIP, 6MM .....	1		
10	94050-06000	NUT, FLANGE, 6MM .....	2		
11	94050-06080	NUT, FLANGE, 6MM .....	1		
12	98200-41000	FUSE, MINI (10A) .....	4		
13	98200-42000	FUSE, MINI (20A) .....	2		