

# PART NAME INDEX

Part name	Page	Ref.	Part name	Page	Ref.	Part name	Page	Ref.
SCREW, FLAT, 4X12 .....	59	17	SHAFT, REDUCTION GEAR .....	41	4	STOPPER COMP., GEARSHIFT DRUM ..	52	7
SCREW, FLAT, 4X45 .....	68	17	SHAFT, ROCKER ARM .....	34	6	STRIPE A, L. SIDE COVER .....	99	10
SCREW, OVAL, 6X45 .....	60	13	SHAFT, WATER PUMP .....	44	5			11
SCREW, PAN, 4X8.5 .....	92	3	SHIM, TAPPET .....	34	14	STRIPE A, R. SIDE COVER .....	99	8
SCREW, PAN, 5X11.5 .....	63	6		35	14			9
SCREW, PAN, 5X14 .....	60	12	SHROUD COMP. ....	36	14	STRIPE B, L. SIDE COVER .....	100	14
	96	14	SHUTTER, KEY .....	92	2			15
SCREW, PAN, 5X15 .....	78	13	SLEEVE, RR. WHEEL .....	91	4	STRIPE B, R. SIDE COVER .....	100	12
SCREW, PAN, 5X25 .....	58	16	SLIDER, CHAIN .....	71	4			13
SCREW, PAN, 6X10 .....	94	12	SLIDER, THROTTLE CABLE .....	82	7	STRIPE C, L. SIDE COVER .....	100	21
	96	13	SLIDER, THROTTLE CABLE .....	58	2	STRIPE C, R. SIDE COVER .....	100	20
SCREW, PAN, 6X14 .....	63	3	SOCKET COMP., POSITION .....	86	2	STRIPE, FR. TOP COVER .....	100	22
	78	14	SPACER, IGNITION COIL .....	89	2	STRIPE, L. RR. BODY COVER .....	100	18
SCREW, PAN, 6X18.5 .....	88	8	SPANNER, 10X12 .....	97	7			19
SCREW, SIDE STAND PIVOT .....	81	6	SPANNER, 10X14 .....	97	8	STRIPE, L. TAIL COVER .....	101	25
SCREW, TAPPING, 3X14 .....	56	6	SPANNER, 12X17 .....	97	9			26
SCREW, TAPPING, 3X16 .....	56	7	SPANNER, 8 .....	97	6	STRIPE, R. RR. BODY COVER .....	100	16
SCREW, TAPPING, 4X12 .....	85	10	SPINDLE COMP., GEARSHIFT .....	52	9			17
SCREW, TAPPING, 4X16 .....	61	21	SPINDLE, KICK STARTER .....	53	5	STRIPE, R. TAIL COVER .....	100	23
	84	18	SPRING ASSY., MAIN STAND .....	81	2			24
	87	10	SPRING C, SIDE STAND .....	81	10	STRIPE, TAIL COVER .....	101	27
	95	17	SPRING, BALANCER GEAR .....	48	9	SUB HARNESS, BATTERY .....	88	2
SCREW, TAPPING, 5X16 .....	55	5	SPRING, BEARING PUSH .....	47	4	SUB HARNESS, FR. ....	89	7
	56	8	SPRING, BRAKE PEDAL .....	79	13	SUSPENSION, ENGINE CONTROL		
	61	20	SPRING, CARBON BRUSH .....	45	3	UNIT	89	19
	84	19	SPRING, CHANGE SWITCH CONTACT ..	52	14	SUSPENSION, RELAY CASE .....	89	14
	86	6	SPRING, CLUTCH .....	40	8	SUSPENSION, WINKER RELAY .....	89	16
	96	17	SPRING, CLUTCH LEVER .....	39	8	SWINGARM SUB ASSY., RR. ....	82	8
SCREW, TAPPING, 5X20 .....	77	17	SPRING, FR. CUSHION REBOUND ..	64	4	SWITCH ASSY., COMBINATION &		
SCREW, TAPPING, 5X25 .....	77	18	SPRING, FR. FORK .....	64	2	LOCK	91	2
SCREW, U-LOCK FLAT, 6X12 .....	91	16	SPRING, GEARSHIFT ARM .....	52	10	SWITCH ASSY., FR. STOP .....	59	1
SCREW, VISOR SPECIAL SETTING ..	60	11	SPRING, GEARSHIFT DRUM STOPPER ..	52	8	SWITCH ASSY., RR. STOP .....	79	10
	76	6	SPRING, GEARSHIFT RETURN .....	52	11	SWITCH ASSY., STARTER MAGNETIC	88	3
	84	13	SPRING, KICK RETURN .....	53	7	SWITCH COMP., COMBINATION &		
	91	15	SPRING, KICK STARTER .....	79	9	LOCK	91	3
	94	10	SPRING, KICK STARTER STOPPER ..	80	1	SWITCH COMP., FR. LEVER .....	58	9
	96	11	SPRING, LOCK KEY SETTING .....	75	3	SWITCH UNIT, DIMMER .....	58	6
SEAL SET, FR. FORK .....	64	12	SPRING, PAD .....	65	9	SWITCH UNIT, HORN .....	58	7
SEAL SET, PISTON .....	65	1		70	4	SWITCH UNIT, STARTER .....	58	5
	70	2	SPRING, RATCHET .....	53	4	SWITCH UNIT, WINKER .....	58	8
SEAL, AIR CLEANER CASE .....	77	5	SPRING, SEAT LOCK .....	75	9			
SEAL, DUST .....	74	7	SPRING, STOP SWITCH .....	79	11	[ T ]		
SEAL, ELEMENT .....	77	3	SPRING, THRUST .....	48	10	TANK COMP., FUEL .....	74	5
		4	SPRING, VALVE INNER .....	34	10	TANK, RADIATOR RESERVE .....	92	14
SEAL, MECHANICAL .....	44	2	SPRING, VALVE OUTER .....	34	9	TENSIONER COMP., CAM CHAIN ..	37	2
SEAL, VALVE STEM .....	34	1	SPROCKET COMP., FINAL DRIVEN ..	71	2	TERMINAL SET, BRUSH .....	45	2
SEAT COMP., DOUBLE .....	75	4	SPROCKET, DRIVE .....	50	18	THERMOSTAT .....	92	17
SEAT, RATCHET SPRING .....	53	6	STAND COMP., MAIN .....	81	1	THREAD COMP., STEERING HEAD		
SEAT, SPRING UPPER .....	64	9	STATOR COMP. ....	43	2	TOP	62	11
SEAT, VALVE SPRING .....	34	12	STAY COMP., FR. TOP COVER .....	91	10	THROTTLE BODY ASSY. ....	54	7
SENSOR ASSY., SPEED .....	47	8	STAY COMP., RESERVE TANK &			CABLE	54	7
SENSOR ASSY., WATER				47	6	TIRE, FR. ....	66	7
TEMPERATURE	32	9	STAY, HARNESS .....	91	7	TIRE, RR. ....	71	11
SENSOR SET .....	54	1	STAY, L. UNDER COVER .....	94	5	TRAY, FUEL .....	74	4
SENSOR, OXYGEN .....	78	10	STAY, RADIATOR LOWER .....	92	8	TUBE, 5X180 .....	39	18
SET RING, 20MM .....	51	34	STAY, R. UNDER COVER .....	94	4	TUBE, 5.3X370 .....	93	32
SET, BANK ANGLE SENSOR .....	89	11	STAY, SEAT HINGE .....	75	1	TUBE, AIR CLEANER CONNECTING ..	77	10
SHAFT, GEARSHIFT FORK .....	52	4	STAY, WIRE .....	54	6	TUBE, BREATHER .....	77	13
			STEM SUB ASSY., STEERING .....	62	10	TUBE, BYPASS .....	92	20

