

PART NAME INDEX

Part name	Address	Page Ref.	Part name	Address	Page Ref.	Part name	Address	Page Ref.
CASE, R. UPPER	F6	49	COVER COMP., L. RR.	D9	32	[E]		
CENTER, CLUTCH	D7	30	COVER COMP., R. CRANKCASE	D6	29	ELEMENT COMP., AIR CLEANER	G5	64
CHAIN, CAM	D4	27	COVER SET, L. SIDE	G4	63	ELEMENT, PRODUCT	F2	45
CHAIN, DRIVE	G11	70	COVER SET, R. SIDE	G4	63			
CHAMBER SET, FLOAT	E3	42	COVER SUB ASSY., AIR CLEANER ..	G5	64			
CIRCLIP, EXTERNAL, 14MM	E1	40	COVER, BATTERY TERMINAL	G16	75			
CIRCLIP, EXTERNAL, 16MM	E2	41	COVER, COMBINATION SWITCH	F7	50	FENDER COMP., FR.	F9	52
CIRCLIP, EXTERNAL, 17MM	E2	41	COVER, L. CRANKCASE	D9	32	FENDER SET, RR.	G13	72
CLAMPER, A.C. GENERATOR CORD ..	D10	33	COVER, L. FR. FORK UPPER	F10	54	FILTER, CUP	G1	60
CLAMP, CORD	F2	45	COVER, L. FR. FORK UPPER	F10	53	FLANGE SUB ASSY., RR. DRIVEN ..	F15	58
CLAMP, TUBE	G5	64	COVER, L. HANDLE LEVER	F11	54	FLAP, TIRE	F13	56
	G6	65	COVER, MAGNETIC SWITCH	F5	48			
CLIP, BREATHER TUBE	G6	65	COVER, MUFFLER	G16	75	FLOAT SET	E3	42
CLIP, HARNESS	H2	77	COVER, R. FR. FORK UNDER	G7	66	FLYWHEEL COMP.	D10	33
CLIP, HOSE	G6	65	COVER, R. FR. FORK UPPER	F10	53	FORK ASSY., L. FR.	F10	53
CLIP, KICK STARTER ARM	G8	67	COVER, R. FR. FORK UPPER	F10	53	FORK ASSY., R. FR.	F10	53
CLIP, PISTON PIN, 14MM	D14	37	COVER, R. HANDLE LEVER	F5	44	FORK, CENTER GEARSHIFT	E1	40
CLIP, TUBE	E4	43	COVER, SOCKET	F1	48	FORK, GEARSHIFT	E1	40
	G1	60	COVER, STARTER MOTOR TERMINAL ..	G16	75	FUEL UNIT	G1	60
	G5	64	COWL, L. RR. SIDE	G3	62	FUSE B	G16	75
	G6	65	COWL, RR. CENTER	G3	62			
	D2	25	COWL, R. RR. SIDE	G3	62			
CLIP, VALVE GUIDE	D2	25	CRANKCASE COMP., L.	D13	36			
CLIP, WIRE, 2X100	G5	64	CRANKCASE COMP., R.	D13	36			
CLIP, WIRE, 4X50	G13	72	CRANKSHAFT COMP.	D14	37			
CLUTCH, ONE WAY	D8	31	CUP SET, FUEL STRAINER	G1	60			
COCK ASSY., FUEL	G1	60	CUSHION ASSY., RR.	G12	71	GASKET B, HEAD COVER	D1	24
COIL ASSY., IGNITION	H1	76	CUSHION, C.D.I. UNIT	H1	76	GASKET C, HEAD COVER	D1	24
COLLAR B, RR. AXLE DISTANCE	F15	58	CUSHION, FR. FORK COVER LOWER ..	F11	54	GASKET SET	E3	42
COLLAR COMP., SWINGARM PIVOT ..	G11	70	CUSHION, FR. FUEL TANK	G1	60	GASKET, BYSTARTER	E3	42
COLLAR, 10MM	D1	24	CUSHION, FR. TOP COVER	G4	63	GASKET, CYLINDER	D5	28
COLLAR, 18.5MM	E2	41	CYLINDER COMP.	D5	28	GASKET, CYLINDER HEAD	D2	25
COLLAR, 6.3X13	F2	45	C.D.I. UNIT	H1	76	GASKET, EX. PIPE	G7	66
COLLAR, 8X6.5	G2	61				GASKET, FLOAT CHAMBER	E3	42
COLLAR, AIR CLEANER	G5	64				GASKET, HEAD COVER	D1	24
	G13	72				GASKET, L. COVER	D9	32
COLLAR, FR. AXLE DISTANCE	F13	56				GASKET, OIL FILTER CAP	D12	35
COLLAR, FR. WHEEL SIDE	F13	56				GASKET, R. CRANKCASE COVER	D6	29
COLLAR, FUEL TANK MOUNT	G1	60				GASKET, TENSIONER LIFTER	D4	27
COLLAR, KICK SPRING	E2	41				GAUGE, OIL LEVEL	D6	29
COLLAR, KICK SPRING	E2	41				GEAR COMP., OIL PUMP	D12	35
COLLAR, L. RR. WHEEL SIDE	F15	58				GEAR, COUNTERSHAFT FIFTH	D15	38
COLLAR, METER	G6	65				GEAR, COUNTERSHAFT FOURTH	D15	38
COLLAR, MUFFLER MOUNTING	G7	66				GEAR, COUNTERSHAFT LOW	D15	38
	F15	58				GEAR, COUNTERSHAFT SECOND	D15	38
COLLAR, RR. AXLE DISTANCE	F15	58				GEAR, COUNTERSHAFT THIRD	D15	38
COLLAR, RR. CUSHION RUBBER	G12	71				GEAR, KICK STARTER IDLE	E2	41
	F14	57				GEAR, MAINSHAFT FIFTH	D15	38
COLLAR, RR. PANEL SIDE	G2	61				GEAR, MAINSHAFT FOURTH	D15	38
COLLAR, RUBBER BUSH	G12	71				GEAR, MAINSHAFT THIRD	D15	38
COLLAR, R. CRANKSHAFT	D14	37				GEAR, MAINSHAFT SECOND	D15	38
COLLAR, STARTER REDUCTION	D8	31				GEAR, PRIMARY DRIVE	D14	37
COLLAR, TAILLIGHT PACKING	G15	74				GEAR, SPEEDOMETER	F12	55
COTTER, VALVE	D3	26				GEAR, STARTER DRIVEN	D8	31
COUNTERSHAFT COMP.	D15	38				GEAR, STARTER REDUCTION	D8	31
COVER B, STARTER MAGNETIC	G16	75				GRIP COMP., THROTTLE	F5	48
COVER COMP., BOTTOM CASE	F10	53				GRIP, L. HANDLE	F5	48
COVER COMP., CYLINDER HEAD	D1	24				GROMMET	F1	44
						GROMMET A, RR. COVER	G6	65
						GROMMET, RR. COWL	G13	72

