

Service item	F.R.T.	Ref. N°	Part. No.	Description	Reqd. Qty. NXR150	Serial No.	Note
OUTER COMP., STARTING CLUTCH0.8 • FLYWHEEL COMP • STATOR COMP		1	28125-KFC-791	OUTER COMP., STARTING CLUTCH.....	1
		2	31110-KRE-901	FLYWHEEL COMP.	1
		3	31120-KRE-901	STATOR COMP.	1
		4	32976-KN6-910	GUIDE, A.C. GENERATOR CORD	1
		5	35750-GS3-003	CONTACT, NEUTRAL SWITCH.....	1
		6	35752-028-300	SPACER, NEUTRAL SWITCH.....	1
		7	90023-KK3-830	BOLT, ROTOR SETTING	1
		8	90085-413-781	BOLT, SOCKET, 6MM.....	6
		9	90089-HB3-000	BOLT, SOCKET, 5X14	2
		10	90403-KN6-930	WASHER, 10X24	1
		11	91312-107-000	O-RING, 7X1.7	1
		12	96001-06020-00	BOLT, FLANGE, 6X20	3
Articulo de servicio	THLL	No. de Ref.	No. de pieza	Descripción	Cant. Reqd. NXR150	No. de serie	Nota
Cubierta Embrague Arranque0.8 • Generador Comp • Ens Estator		1	28125-KFC-791	Cubierta Embrague Arranque	1
		2	31110-KRE-901	Generador Comp	1
		3	31120-KRE-901	Ens Estator.	1
		4	32976-KN6-910	Guia Alambraje Generador.....	1
		5	35750-GS3-003	Contacto Interruptor Neutro	1
		6	35752-028-300	Espaciador Interruptor Neutro	1
		7	90023-KK3-830	Perno Fijación Rotor	1
		8	90085-413-781	Perno Allen, 6mm	6
		9	90089-HB3-000	Perno Allen, 5X14	2
		10	90403-KN6-930	Arandela, 10X24	1
		11	91312-107-000	Anillo O, 7X1.7	1
		12	96001-06020-00	Perno Reborde, 6X20	3