


F-4

HANDLE LEVER/SWITCH/CABLE

F 4



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	811100	(5) CABLE, THROTTLE	2.8
		.NOTE: Same time for two units	
7	6151E2	SWITCH, HAZARD	0.3
8	615116	SWITCH, STARTER	0.3
10	8101K8	HOUSING, STARTER SWITCH	2.9
11	615117	SWITCH, DIMMER	0.3
12	6151A3	SWITCH, HORN	0.3
13	6151C4	SWITCH, IDLE	0.3
14	615118	SWITCH, WINKER	0.3
16	8101K9	HOUSING, WINKER SWITCH	2.8
17	6151C6	SWITCH, LEFT START	0.2
18	6151B3	SWITCH, REAR STOP :LEVER SIDE	0.2
	6151B6	SWITCH, STOP :BOTH	0.3
19	8111E1	CABLE, REAR BRAKE FIRST	1.7
21	810150	GRIP, THROTTLE	0.9
22	8101C0	GRIP, HANDLE :LEFT	0.1
23	8101C8	BRACKET, HANDLE LEVER :LEFT ..	0.3
25	8101C6	LEVER, HANDLE :LEFT	0.1
	8101F5	LEVER, HANDLE :BOTH	0.2

Ref. No.	Part No.	Description	Reqd. QTY WW150 F	Serial No.	Parts catalogue code
1	17910-K36-T01	CABLE COMP. A, THROTTLE	1		
2	17912-K35-V00	CLAMPER A, THROTTLE CABLE ...	1		
3	17913-K35-V00	CLAMPER B, THROTTLE CABLE ...	1		
4	17914-K35-V00	CLAMPER C, THROTTLE CABLE ...	1		
5	17920-K36-T01	CABLE COMP. B, THROTTLE	1		
6	32161-404-000	BAND B1, WIRE	2		
7	35150-K35-J01	SWITCH UNIT, HAZARD	1		
8	35160-KYZ-901	SWITCH UNIT, STARTER	1		
9	35164-GGZ-J02	HOUSING, STARTER SWITCH RR. -	1		
10	35165-K35-J01	HOUSING COMP., STARTER SWITCH	1		
11	35170-K35-V01	SWITCH UNIT, DIMMER	1		
12	35180-K03-N31	SWITCH UNIT, HORN(TOYO DENSO)	1		
13	35190-KWN-901	SWITCH UNIT, IDLE	1		
14	35200-K35-V01	SWITCH UNIT, WINKER	1		
15	35202-GGZ-J02	HOUSING, WINKER SWITCH RR. ..	1		
16	35205-K35-V01	HOUSING COMP., WINKER SWITCH	1		
17	35340-K35-V01	SWITCH ASSY., L. STARTER	1		
18	35345-K35-V01	SWITCH ASSY., RR. STOP	1		
19	43440-K36-T01	CABLE COMP., RR. BRAKE FIRST	1		
20	45517-166-006	HOLDER, MASTER CYLINDER	1		
21	53140-K35-V00	GRIP COMP., THROTTLE	1		
22	53166-KWN-900	GRIP, L. HANDLE	1		
23	53172-K35-V00	BRACKET, L. HANDLE LEVER	1		
24	53177-K35-V00	BOOT, L. LEVER	1		
25	53178-K35-V00	LEVER, L. STEERING HANDLE ...	1		