


# F - 18

# Pedal



KEHG - GL156S

No.	Part Number	Description	Q'ty
1	24701-KEH-930	PEDAL, GEAR CHANGE .....	1
2	28241-KC5-010	JOINT, KICK ARM .....	1
3	28293-333-000	CLIP, KICK STARTER ARM .....	1
4	28300-KC5-010	ARM ASSY., KICK STARTER .....	1
5	28311-KC5-000	RUBBER, KICK STARTER .....	1
6	28333-124-000	SPRING, KICK STARTER STOPPER .....	1
7	35350-KEH-950	SWITCH ASSY., RR. STOP .....	1
8	35357-KC5-000	SPRING, STOP SWITCH .....	1
9	43451-KEH-900	ROD, RR. BRAKE .....	1
10	46500-KC5-000	PEDAL, BRAKE .....	1
11	46514-383-830	SPRING, BRAKE PEDAL .....	1
12	90505-116-670	WASHER, 13X20 .....	1
13	94101-05000	WASHER, PLAIN, 5MM .....	1
14	94201-20150	PIN, SPLIT, 2.0X15 .....	1
15	95011-40000	RUBBER, CHANGE PEDAL .....	1
16	95014-73100	SPRING A, BRAKE ROD .....	1
17	95015-32001	JOINT B. BRAKE ARM .....	1
18	95015-42000	NUT B. BRAKE ROD ADJUSTING .....	1
19	95701-06020-00	BOLT, FLANGE, 6X20 .....	1
20	95701-08040-00	BOLT, FLANGE, 6X40 .....	1
21	96211-08000	BALL, STEEL, #8 (1/4) .....	1

3

06.01.1998