


F - 21

Pedal / Kick Starter Arm



No.	Service item	F.R.T.	No.	Part Number	Description	QTY	Notes
1	PEDAL, GEAR CHANGE	0.1	1	24701-KCJ-690	PEDAL, GEAR CHANGE	1	
2	ARM, GEAR CHANGE	0.1	2	24711-KCJ-690	ARM, GEAR CHANGE	1	
8	ARM, KICK STARTER	0.1	3	24720-KBW-900	ROD, TIE	1	
12	SWITCH, REAR STOP :PEDAL SIDE	0.2	4	24721-KW1-900	COVER, CHANGE PEDAL	2	
14	ROD, REAR BRAKE	0.4	5	24781-KR3-770	RUBBER, GEAR CHANGE PEDAL	1	
15	PEDAL, REAR BRAKE	0.1	6	28241-KCJ-690	JOINT, KICK ARM	1	
25	ARM, BRAKE MIDDLE :REAR	0.4	7	28293-333-000	CLIP, KICK STARTER ARM	1	
			8	28300-KCJ-690	ARM ASSY., KICK STARTER	1	
			9	28307-KCJ-690	STOPPER, KICK ARM	1	
			10	28311-KC5-000	RUBBER, KICK STARTER	1	
			11	28333-KK0-000	SPRING, KICK STARTER	1	
			12	35350-KCJ-661	SWITCH ASSY., RR. STOP	1	
			13	35357-KCJ-690	SPRING, STOP SWITCH	1	
			14	43451-KCJ-880	ROD COMP., RR. BRAKE	1	SW
			15	46500-KCJ-660	PEDAL, BRAKE	1	
			16	46510-KCJ-690	SPRING ASSY., RR. BRAKE PEDAL	1	SW
			17	46514-KN5-670	SPRING, BRAKE PEDAL	1	CW
			18	46515-KBW-900	ARM COMP., MIDDLE	1	SW
			19	46515-KCJ-670	ARM COMP., MIDDLE	1	CW
			20	90502-155-000	WASHER, PLAIN, 7MM	2	