

E-2 Breaker · Advancer

Ref. No.	Part No.	Description	Reqd. No. XL250	Serial No.	Area Code
1	30200-329-004	BREAKER ASSY., CONTACT (ND)	1		
2	30201-329-004	PLATE, CONTACT BREAKER BASE	1		
3	30202-107-004	BREAKER, CONTACT (ND)	1		
4	30205-028-004	FELT, OIL (ND)	1		
5	30220-329-024	ADVANCER ASSY., SPARK (ND)	1		
6	30225-246-004	BOLT, SPARK ADVANCER SETTING	1		
7	30370-329-000	COVER, CONTACT BREAKER	1		
8	30372-329-000	GASKET, CONTACT BREAKER COVER	1		
9	90417-035-303	WASHER, SHIFT DRUM SIDE	1		
10	90482-028-000	WASHER, 5MM	2		
11	93500-05010-0A	SCREW, PAN, 5X10	2		
12	93700-05022-0B	SCREW, OVAL, 5X7	2		
13	94101-04000	WASHER, PLAIN, 4MM	2		
14	94111-04000	WASHER, SPRING, 4MM	2		
15	99500-04007-0A	SCREW, HOLLOW PAN, 4X7	2		