




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	110120	CRANKCASE :RIGHTINCLUDES: Engine removal and installation	5.3
5	1101L3	ONE WAY VALVE, CRANKCASEINCLUDES: Engine removal and installation	4.8
6	110115	CRANKCASE :LEFTINCLUDES: Engine removal and installation	5.7
	1101A2	CRANKCASE :BOTHINCLUDES: Engine removal and installation	5.9
8	1101B7	BEARING, CRANKSHAFT :RIGHTINCLUDES: Engine removal and installation	5.2
9	1101B6	BEARING, CRANKSHAFT :LEFTINCLUDES: Engine removal and installation	5.2
	1101G0	BEARING, CRANKSHAFT :BOTHINCLUDES: Engine removal and installation	5.4
10	1131B6	STRAINER, OIL	1.4
13	113126	VALVE, RELIEFINCLUDES: Engine removal and installation	4.8

Ref. No.	Part No.	Description	Reqd. QTY NSS 300 D	NSS 300A D	Serial No.	Parts catalogue code
1	11100-K04-932	CRANKCASE COMP., R.	1	1		
2	11103-K04-930	BUSH, R. OUTER ENGINE HANGER	1	1		
3	11104-K04-930	BUSH, L. OUTER ENGINE HANGER	1	1		
4	11105-KTW-900	BUSH, INNER ENGINE HANGER ...	2	2		
5	11110-KTW-901	VALVE COMP., REED	1	1		
6	11200-K04-931	CRANKCASE COMP., L.	1	1		
7	11205-KTW-900	GASKET, OIL PATH	1	1		
8	13312-KTW-901	BEARING A, CRANKSHAFT R. SIDE (BLUE)	2	2		
	13313-KTW-901	BEARING B, CRANKSHAFT R. SIDE (BLACK)	2	2		
	13314-KTW-901	BEARING C, CRANKSHAFT R. SIDE (BROWN)	2	2		
	13315-KTW-901	BEARING D, CRANKSHAFT R. SIDE (GREEN)	2	2		
	13316-KTW-901	BEARING E, CRANKSHAFT R. SIDE (BLUE/BLUE) (O.S.)	(2)	(2)		
	13317-KTW-901	BEARING F, CRANKSHAFT R. SIDE (BLACK/BLACK) (O.S.)	(2)	(2)		
	13318-KTW-901	BEARING G, CRANKSHAFT R. SIDE (BROWN/BROWN) (O.S.)	(2)	(2)		
	13319-KTW-901	BEARING H, CRANKSHAFT R. SIDE (GREEN/GREEN) (O.S.)	(2)	(2)		
9	13322-KTW-901	BEARING A, CRANKSHAFT L. SIDE (BLUE)	2	2		
	13323-KTW-901	BEARING B, CRANKSHAFT L. SIDE (BLACK)	2	2		