


F-10-1

STEERING STEM/COMBINATION SWITCH(KO/U)

F16



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	6151D2	KEY SET(A)	2.0
2	6151A2	KEY, SHUTTER	1.8
		.EXCLUDES: Key cutting	
3	6151E9	SWITCH, COMBINATION & LOCK(A)	2.0
4	6151C2	BASE, CONTACT	1.9
6		(8)	
	6151E8	SWITCH, SEAT AND BOX	1.7
14	510100	STEM OR SHAFT ASSY., STEERING (12)	2.1
15		(12)	
	5101B2	THREAD, STEERING HEAD TOP	1.9
20	5101B6	BEARING, HEAD PIPE :UPPER	2.1
21		(13)	
	5101B7	BEARING, HEAD PIPE :LOWER	2.3
	5101C7	BEARING, HEAD PIPE :BOTH	2.3

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			NSS 300 D	NSS 300A D		
1	35010-K04-900	KEY SET	1	1	-----	KO,U
2	35011-K04-305	KEY SET, SHUTTER	1	1	-----	KO,U
3	35100-K04-901	SWITCH ASSY., COMBINATION & LOCK	1	1	-----	KO,U
4	35101-K04-931	BASE COMP., CONTACT	1	1	-----	KO,U
5	35121-KYE-900	KEY, BLANK			-----	
		(90KEYTOP2REPORDER)	(1)	(1)	-----	KO,U
6	35190-K27-V01	SWITCH ASSY., FUEL LID & SEAT OPENER	1	1	-----	KO,U
7	35191-K27-V01	COVER, CABLE	2	2	-----	KO,U
8	35195-K04-931	SWITCH ASSY., L. LID OPENER ..	1	1	-----	KO,U
9	50211-K04-930	STAY COMP., INNER	1	1	-----	KO,U
10	50306-GN5-900	NUT, STEERING STEM LOCK	1	1	-----	KO,U
11	53113-MCT-010	SEAL, HANDLE POST	1	1	-----	KO,U
12	53213-MB4-771	DUST SEAL, STEERING UPPER (ARAI)	1	1	-----	KO,U
13	53214-MR7-003	DUST SEAL, STEERING HEAD(ARAI)	1	1	-----	KO,U
14	53219-K04-930	STEM SUB ASSY., STEERING	1	1	-----	KO,U
15	53220-KYJ-900	THREAD COMP., STEERING HEAD TOP	1	1	-----	KO,U
16	90101-MT4-000	SCREW, SCREEN SETTING	4	4	-----	KO,U
17	90102-KVZ-630	BOLT, FLANGE, 10X45	4	4	-----	KO,U
18	90107-MBG-000	BOLT, ONE-WAY, 8MM	2	2	-----	KO,U
19	90506-MCT-000	WASHER, LOCK NUT	1	1	-----	KO,U
20	91015-KT8-005	BEARING, HEAD PIPE UPPER(KOYO)	1	1	-----	KO,U

