


Catalog Title:  
**GL1500 '88 '89 '90 GL1500SE '90 '91 GL1500A '91 GL1500I '91 F 3201**

Block No.

Block Title:  
**BATTERY '90-'91 EXCEPT - I**



Ref. No.	Part No.	Description
22	50328-MN5-000	TUBE, BATTERY
23	83119-MG9-000	COLLAR, LOCK SETTING
24	83618-323-000	RUBBER, BATTERY BOX
25	90071-MB0-000	NUT-WASHER (6MM)
26	90109-434-000	BOLT (6MM)
27	90153-SB2-003	SCREW-WASHER (5X10)
28	90303-HA0-680	NUT, SPECIAL (6X7)
29	92301-06012-0A	BOLT, SLOT (6X12)
30	93891-06016-08	SCREW-WASHER (6X16)
31	94002-06080-0S	NUT, HEX. (6MM)
32	94050-06080	NUT, FLANGE (6MM)
33	94101-06800	WASHER, PLAIN (6MM)
34	94111-06800	WASHER, SPRING (6MM)
35	95701-06012-08	BOLT, FLANGE (6X12)
36	95701-06016-08	BOLT, FLANGE (6X16)
37	98200-33000	FUSE, BLADE (30A)
37	32507-SM4-003	FUSE (F30)
38	98200-65500	FUSE G (55A)