

MAINTENANCE

MAINTENANCE SCHEDULE

Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult their authorized Honda dealer.

ITEMS	FREQUENCY	ODOMETER READING (NOTE 1)							REFER TO PAGE		
		x 1,000 mi x 100 km	0.6 10	4 64	8 128	12 192	16 256	20 320		24 384	
EMISSION RELATED ITEMS	* FUEL LINE				I		I		I	4-5	
	* THROTTLE OPERATION				I		I		I	4-7	
	* AIR CLEANER	NOTE 2				R			R	4-8	
	* SPARK PLUG		EVERY 16,000 mi (25,600 km): I, EVERY 32,000 mi (51,200 km): R							4-8	
	* VALVE CLEARANCE						I			4-16	
	ENGINE OIL			R		R		R		R	4-21
	ENGINE OIL FILTER			R		R		R		R	4-21
	* ENGINE IDLE SPEED			I	I	I	I	I	I	I	4-24
	RADIATOR COOLANT	NOTE 3				I		I		R	4-24
	* COOLING SYSTEM					I		I		I	4-24
	* SECONDARY AIR SUPPLY SYSTEM					I		I		I	4-25
	* EVAPORATIVE EMISSION CONTROL SYSTEM	NOTE 4					I			I	4-26
** EXHAUST GAS CONTROL VALVE CABLE		EVERY 16,000 mi (25,600 km): I							4-34		
NON-EMISSION RELATED ITEMS	DRIVE CHAIN		EVERY 500 mi (800 km): I, L							4-26	
	BRAKE FLUID	NOTE 3			I	I	R	I	I	R	4-30
	BRAKE PAD WEAR				I	I	I	I	I	I	4-31
	BRAKE SYSTEM			I		I		I		I	4-32
	* BRAKE LIGHT SWITCH				I		I		I	I	4-33
	* HEADLIGHT AIM				I		I		I	I	4-33
	CLUTCH SYSTEM			I	I	I	I	I	I	I	4-33
	SIDE STAND				I		I		I	I	4-36
	* SUSPENSION				I		I		I	I	4-37
	* NUTS, BOLTS, FASTENERS			I		I		I		I	4-41
	** WHEELS/TIRES				I		I		I	I	4-41
** STEERING HEAD BEARINGS			I		I		I		I	4-41	

* Should be serviced by an authorized Honda dealer, unless the owner has proper tools and service data and is mechanically qualified.

** In the interest of safety, we recommended these items be serviced only by an authorized Honda dealer.

NOTES:

- At higher odometer reading, repeat at the frequency interval established here.
- Service more frequently if the motorcycle is ridden in unusually wet or dusty areas.
- Replace every 2 years, or at indicated odometer interval, whichever comes first. Replacement requires mechanical skill.
- California type only.