

FRONT WHEEL/SUSPENSION/STEERING

Drive the oil seal in using the special tool.

TOOL:

Fork seal driver, 43 mm

07YMD-MCF0100 or
07NMD-KZ3010A
(U.S.A. only)

*Do not scratch the
fork tube sliding
surface.*

Install the stopper ring into the fork slider groove
securely.

Install the dust seal into the fork slider.

Install the fork damper assembly into the fork slider.

