

INDEX

LUBRICATION SYSTEM SPECIFICATIONS	1-6
MAIN JOURNAL BEARING.....	13-9
MAINTENANCE SCHEDULE.....	4-4
MAP SENSOR.....	6-64
MIL CODE INDEX	6-13
MIL TROUBLESHOOTING	6-15
MODEL IDENTIFICATION	1-2
NEUTRAL SWITCH.....	20-21
NUTS, BOLTS, FASTENERS.....	4-41
OIL COOLER	5-13
OIL PRESSURE INSPECTION	5-5
OIL PUMP	5-8
OIL STRAINER/PRESSURE RELIEF VALVE.....	5-6
PAIR CONTROL SOLENOID VALVE	6-71
PASSENGER SEAT.....	3-4
PGM-FI SELF-DIAGNOSIS INFORMATION	6-9
PISTON/CYLINDER.....	13-15
POSITION LIGHT.....	20-6
PRIMARY INJECTOR.....	6-54
RADIAL-MOUNTED FRONT BRAKE CALIPER.....	2-5
RADIATOR	7-10
RADIATOR COOLANT.....	4-24
RADIATOR RESERVE TANK	7-20
REAR BRAKE CALIPER.....	16-31
REAR FENDER.....	3-19
REAR MASTER CYLINDER	16-21
REAR SEAT COWL	3-5
REAR WHEEL.....	15-7
REAR WHEEL/SUSPENSION SPECIFICATIONS.....	1-9
REGULATOR/RECTIFIER.....	17-8
RIDER SEAT	3-4
RIGHT CRANKCASE COVER INSTALLATION	10-34
RIGHT CRANKCASE COVER REMOVAL.....	10-15
SEAT RAIL	3-27
SECONDARY AIR SUPPLY SYSTEM	4-25
SECONDARY INJECTOR.....	6-43
SERVICE INFORMATION	
ALTERNATOR	11-3
BATTERY/CHARGING SYSTEM.....	17-3
CLUTCH/STARTER CLUTCH/GEARSHIFT	
LINKAGE.....	10-4
COOLING SYSTEM.....	7-3
CRANKCASE/CRANKSHAFT/BALANCER/ PISTON/CYLINDER	13-3
CRANKCASE/TRANSMISSION	12-4
CYLINDER HEAD/VALVES.....	9-3
ELECTRIC STARTER	19-3
ENGINE REMOVAL/INSTALLATION	8-3
FRAME/BODY PANELS/EXHAUST SYSTEM	3-3
FRONT WHEEL/SUSPENSION/STEERING.....	14-3
FUEL SYSTEM (Programmed Fuel Injection).....	6-3
HYDRAULIC BRAKE.....	16-4
IGNITION SYSTEM	18-3
LIGHTS/METERS/SWITCHES.....	20-3
LUBRICATION SYSTEM	5-3
MAINTENANCE	4-2
REAR WHEEL SUSPENSION	15-3
SERVICE RULES	1-2
SHOCK ABSORBER.....	15-14
SIDE STAND	4-36
SIDE STAND SWITCH.....	20-22
SPARK PLUG	4-8
SPEEDOMETER/VEHICLE SPEED SENSOR.....	20-11
STANDARD TORQUE VALUES.....	1-12
STARTER CLUTCH.....	10-28
STARTER MOTOR	19-6
STARTER RELAY SWITCH	19-13
STATOR.....	11-4
STEERING DAMPER	14-34
STEERING HEAD BEARINGS.....	4-41
STEERING STEM	14-35
SUSPENSION.....	4-37
SUSPENSION LINKAGE.....	15-17
SWINGARM	15-20
SYSTEM DIAGRAM	
BATTERY/CHARGING SYSTEM	17-2
ELECTRIC STARTER.....	19-2
FUEL SYSTEM (Programmed Fuel Injection)	6-8
IGNITION SYSTEM	18-2
SYSTEM FLOW PATTERN	7-2
SYSTEM LOCATION	
FUEL SYSTEM (Programmed Fuel Injection)	6-7
LIGHTS/METERS/SWITCHES	20-2
SYSTEM TESTING	7-5
TACHOMETER	20-13
TAIL/BRAKE LIGHT	20-8
THERMOSTAT	7-8
THROTTLE BODY.....	6-47
THROTTLE OPERATION.....	4-7
TOP SHELTER	3-16
TRANSMISSION	12-11
TRANSMISSION/GEARSHIFT LINKAGE	
SPECIFICATIONS	1-8
TROUBLESHOOTING	5-4
BATTERY/CHARGING SYSTEM	17-4
CLUTCH/GEARSHIFT LINKAGE	10-5
COOLING SYSTEM	7-4
CRANKCASE/CRANKSHAFT/BALANCER/ PISTON/CYLINDER.....	13-4
CRANKCASE/TRANSMISSION	12-6
CYLINDER HEAD/VALVES	9-5
ELECTRIC STARTER.....	19-4
ENGINE DOES NOT START OR IS HARD	
TO START	22-2
ENGINE LACKS POWER	22-3
FRAME/BODY PANELS/EXHAUST SYSTEM.....	3-3
FRONT WHEEL/SUSPENSION/STEERING	14-6
FUEL SYSTEM (Programmed Fuel Injection)	6-6
HYDRAULIC BRAKE	16-6
IGNITION SYSTEM	18-4
POOR HANDLING	22-6
POOR PERFORMANCE AT HIGH SPEED.....	22-6
POOR PERFORMANCE AT LOW AND	
IDLE SPEED	22-5
REAR WHEEL SUSPENSION.....	15-6
TURN SIGNAL.....	20-7
TURN SIGNAL RELAY	20-24
UNDER COWLS/MIDDLE COWLS	3-7
UPPER COWL	3-12
VALVE CLEARANCE	4-16
VALVE GUIDE REPLACEMENT.....	9-18
VALVE SEAT INSPECTION/REFACING	9-19
WATER PUMP.....	7-17
WHEELS/TIRES	4-41
WIRING DIAGRAM	
A, AC, CM type	21-3