

Requisite Service

- Side fairing removal/installation(page 2-3)

	Procedure	Q'ty	Remarks
Removal Order			
(1)	Rear view mirror inner cover	1/1	
(2)	Bolt	4	
(3)	Rear view mirror (right/left)	1/1	
(4)	Seat rubber plate	2	
(5)	Seat rubber	2	
(6)	Wind screen	1	
(7)	Seat rubber	2	
(8)	Front turn signal light connector(3P mini)	2	
(9)	Position light connector(2P mini)	1	
(10)	Headlight socket	1	
(11)	Hex bolt	2	
(12)	Front cowl	1	
Installation Order			
(12)	Front cowl	1	Align the bosses on the headlight case with the grommets.
(11)	Hex bolt	2	
(10)	Headlight socket	1	
(9)	Position light connector(2P mini)	1	
(8)	Front turn signal light connector(3P mini)	2	
(7)	Seat rubber	2	
(6)	Wind screen	1	
(5)	Seat rubber	2	Install the right seat rubber with the mark "MT4-R" facing in.
			Install the left seat rubber with the mark "MT4-L" facing in.
			Install the right plate with the marked side in and each arrow mark pointing forward and up.
(4)	Seat rubber plate	2	Install the left plate with the marked side out and each arrow mark pointing forward and up.
(3)	Rear view mirror(right/left)	1/1	
(2)	Bolt	4	
(1)	Rear view mirror inner cover	1/1	