



**MODEL IDENTIFICATION**



**SERIAL NUMBERS**

The frame serial number is stamped on the right side of the frame near the regulator.



The engine serial number is stamped on the left side of the crankcase.

