

FRONT WHEEL/SUSPENSION/STEERING

| ITEM | Q'TY | THREAD DIA. (mm) | TORQUE N·m (kgf·m, lbf·ft) | REMARKS |
|------------------------------|------|------------------|----------------------------|-------------------------------------|
| Front brake disc socket bolt | 4 | 8 | 42 (4.3, 31) | ALOC bolt; replace with a new one. |
| Front axle nut | 1 | 12 | 59 (6.0, 44) | U-nut |
| Fork socket bolt | 2 | 8 | 20 (2.0, 15) | Apply locking agent to the threads. |
| Fork pinch bolt | 4 | 10 | 49 (5.0, 36) | |
| Fork cap bolt | 2 | 26 | 23 (2.3, 17) | |
| Handlebar post nut | 1 | 10 | 33 (3.4, 24) | See page 15-22 |
| Steering stem lock nut | 1 | BC 1 | - | See page 15-26 |
| Steering stem adjusting nut | 1 | BC 1 | - | See page 15-26 |

REAR WHEEL/SUSPENSION

| ITEM | Q'TY | THREAD DIA. (mm) | TORQUE N·m (kgf·m, lbf·ft) | REMARKS |
|---------------|------|------------------|----------------------------|---|
| Rear axle nut | 1 | 16 | 118 (12.0, 87) | Apply engine oil to the threads and seating surface. U-nut |

BRAKE SYSTEM

| ITEM | Q'TY | THREAD DIA. (mm) | TORQUE N·m (kgf·m, lbf·ft) | REMARKS |
|---------------------------------------|------|------------------|----------------------------|------------------------------------|
| Brake caliper bleed valve | 1 | 8 | 5.4 (0.55, 4.0) | |
| Master cylinder reservoir cap screw | 2 | 4 | 1.5 (0.15, 1.1) | |
| Brake caliper mounting bolt | 2 | 8 | 30 (3.1, 22) | ALOC bolt; replace with a new one. |
| Brake pad pin | 2 | 10 | 17.2 (1.8, 13) | |
| Brake pad pin plug | 2 | 10 | 2.4 (0.25, 1.8) | |
| Front brake light switch screw | 1 | 4 | 1.2 (0.12, 0.9) | |
| Front brake lever pivot screw | 1 | 6 | 1.0 (0.10, 0.7) | |
| Front brake lever pivot nut | 1 | 6 | 5.9 (0.60, 4.4) | |
| Brake master cylinder holder bolt | 2 | 6 | 12 (1.2, 9) | |
| Brake hose oil bolt | 2 | 10 | 34 (3.5, 25) | |
| Rear brake lever pivot screw | 1 | 5 | 1.0 (0.10, 0.7) | |
| Rear brake lever pivot nut | 1 | 5 | 4.5 (0.46, 3.3) | U-nut |
| Equalizer rod pivot screw | 1 | 5 | 1.0 (0.10, 0.7) | |
| Equalizer rod pivot nut | 1 | 5 | 4.5 (0.5, 3.3) | U-nut |
| Equalizer bracket cover screw | 2 | 5 | 4.2 (0.43, 3.1) | |
| Equalizer bracket cover special screw | 1 | 5 | 4.2 (0.43, 3.1) | |
| Rear brake arm bolt | 1 | 6 | 10 (1.0, 7) | ALOC bolt; replace with a new one. |