

3. FRAME/BODY PANELS/EXHAUST SYSTEM

BODY PANEL LOCATIONS	3-2	UNDER COVER.....	3-7
BODY PANEL REMOVAL CHART	3-2	SEAT	3-8
SERVICE INFORMATION	3-3	GRAB RAIL/CARRIER.....	3-8
TROUBLESHOOTING	3-3	LUGGAGE BOX	3-8
FRONT FENDER.....	3-4	FRONT BODY COVER	3-9
FRONT CENTER COVER	3-4	BODY COVER	3-9
SIDE BODY COVER	3-4	FLOOR PANEL	3-11
FLOOR PANEL SIDE COVER.....	3-5	FRONT INNER COVER	3-12
FRONT COVER.....	3-6	REAR FENDER	3-12
REAR VIEW MIRROR.....	3-6	RADIATOR COVER.....	3-13
FRONT HANDLEBAR COVER	3-6	EXHAUST PIPE/MUFFLER	3-13
REAR HANDLEBAR COVER.....	3-7	CENTERSTAND	3-14