4. MAINTENANCE

SERVICE INFORMATION4-2	DRIVE BELT 4-14
MAINTENANCE SCHEDULE 4-4	FINAL DRIVE OIL 4-15
FUEL LINE 4-5	BRAKE FLUID 4-16
THROTTLE OPERATION4-5	BRAKE SHOES/PADS WEAR 4-16
AIR CLEANER 4-6	BRAKE SYSTEM 4-17
CRANKCASE BREATHER 4-7	BRAKE LIGHT SWITCH 4-20
SPARK PLUG 4-8	BRAKE LOCK OPERATION 4-20
VALVE CLEARANCE4-9	HEADLIGHT AIM 4-20
ENGINE OIL 4-10	CLUTCH SHOES WEAR 4-21
ENGINE OIL STRAINER SCREEN 4-12	SUSPENSION 4-21
ENGINE IDLE SPEED 4-13	NUTS, BOLTS, FASTENERS 4-22
RADIATOR COOLANT 4-13	WHEELS/TIRES 4-22
COOLING SYSTEM······ 4-14	STEERING HEAD BEARINGS 4-24